

## SIZE GUIDE //

### DEXSHELL WATERPROOF SOCKS & OVERSHOES:

The chart shows the general guidelines for Dexshell Socks and Overshoe sizes (unisex). If you are in between sizes then we recommend you choose a larger size.

SIZE	EURO	UK	US (MEN)	US (WOMEN)	CM
SMALL	36-38	3-5	4-6	5-7	22-24
MEDIUM	39-42	6-8	6.5-9	7.5-10	24-26
LARGE	43-46	9-11	9.5-12	10.5-13	26-28
X LARGE	47-49	12-14	12.5-14.5		28-30

### DEXSHELL WATERPROOF CHILDREN'S SOCKS:

SIZE	EURO	UK	US	CM
SMALL	28-30	9-12	11-12.5	16-18
MEDIUM	30-33	12-1	13-2	18-20
LARGE	33-36	1-3	2-4	20-22

